# WATTS BRIDGE

#### **FLEV 300** FULL NOTAM SERVICE NOT AVBL

UTC +10 YWSG 1522735F VAR 11 DEG E UNCR

AD OPR Watts Bridge Memorial Airfield Association, PO Box 98, Toogoolawah. QLD. 4313. Email: info@wattsbridge.com.au. PH 0427 699 239. Website: www.wattsbridge.com.au.

# REMARKS

- PPR for all commercial OPS, including flight training. 1.
- 2. Commercial operators to email AD OPR for permission. Charges and/or conditions apply.

### HANDLING SERVICES AND FACILITIES

OI D

270544S

AVGAS available - self serve swipe card - MC and V only.

### PHYSICAL CHARACTERISTICS

03/21	27c	Unrated. Grass. RWY LEN 810M.	WID 25
12L/30R	28c	Unrated. Grass. RWY LEN 840M.	WID 30
12R/30L	29c	Unrated. Grass. RWY LEN 880M.	WID 30
The extension to BM	V 12R/2	ROL is only AVRL by prior arrangement	The extension trave

averses by prior arrangem Silverleaves Rd and the airfield perimeter fence. When not in use the DTHR RWY 12R is located on the SE side of Silverleaves Rd.

#### ATS AND AERODROME COMMUNICATION FACILITIES 129.0 Circuit Area

FIA BRISBANE CENTRE

## LOCAL TRAFFIC REGULATIONS

- 1. Carriage and use of radio is required by AD OPR.
- Access to RWY 12L and 30R at RWY ends only. 2.
- Taxi on mown SFC and exit TWY to parking areas by marked access points only. 3.

# FLIGHT PROCEDURES

Right hand circuits RWY 12R and 30R.

#### **CTAF** 127.3

## NOISE ABATEMENT PROCEDURES

- Circuits not permitted before 0700 Local. 1.
- Consult website for Fly Neighbourly information. 2.

#### ADDITIONAL INFORMATION

- Weather camera display AVBL on website. 1.
- 2. Aerobatic operations may take place WI 2NM SE of the airfield, up to 5,000FT. Refer Watts Bridge Fly Neighbourly Map for the location of the aerobatics box. AVBL FM website.
- 3. Intensive skydiving at Toogoolawah, 5NM NW of Watts Bridge.
- Pilots should check for airfield status updates via website. 4.
- Drainage ditches flank each TWY. 5.

# CHARTS RELATED TO THE AERODROME

WAC 3340.