

27 FEB 2020

**1 - PERTH-DEPARTING AIRCRAFT**

- 1.1 - Whenever possible, complete cockpit checks prior to lineup and keep any checks requiring completion on the runway to a minimum.
- 1.2 - On receipt of line up clearance, taxi into position as soon as possible. Do not backtrack.
- 1.3 - Pilots and ATC should endeavour to keep aircraft moving and avoid a standing start.
- 1.4 - Commence the take off roll as soon as take off clearance is issued.

**2 - PERTH-ARRIVING AIRCRAFT**

- 2.1 - By day, ATC may use 2,400M runway separation between aircraft arriving to RWY 03/21. Both aircraft may occupy the runway during application of the standard.
- 2.2 - To ensure minimum runway occupancy time and support optimum spacing on final, whenever operational conditions permit, expect to vacate the runway via the exit taxiways specified in the table below.
- 2.3 - Plan a predictable and efficient exit from the runway and, if an exit other than the preferred is required, advise tower on first contact.
- 2.4 - Landing Exit Distance (LED), the distance from the threshold to the furthest edge of the exit taxiway, are provided to assist planning.

	<b>Aircraft Type</b>	<b>PREFERRED Exits</b>	<b>LED (Metres)</b>
<b>RWY 03</b>	<b>Non-Jet Jet F100/E195/RJ1H and BLW</b>	<b>A6/C6</b>	<b>1588</b>
	<b>Jet ABV F100/E195/RJ1H</b>	<b>P D</b>	<b>1975 2640</b>
<b>RWY 21</b>	<b>Non-Jet Jet Light, Medium</b>	<b>A6/C6</b>	<b>1777</b>
	<b>Jet Heavy</b>	<b>A7 C9</b>	<b>1984 2484</b>
<b>RWY 24</b>	<b>All</b>	<b>J1/A#</b>	<b>1636</b>

Note 1: Aircraft may vacate at an earlier exit without ATC approval.

Note 2: # These exits have different LEDs if vacating left or right and the distance promulgated is the shortest of these LEDs.

Note 3: Preferred exits for RWY 06 not promulgated due infrequent use.